

Specification

PolyBond Latex Based Drywall and Panel Adhesive



POLYBOND is a solvent free polyvinyl acetate adhesive for installing drywall, hardboard, paneling, and wood sheet of any type. It conforms to ASTM 72-80 and ASTM C-557-73. It contains no ingredients harmful to health or the environment. Polybond is not suitable for water contact areas.

4. Preheat building to a minimum of 65°F and 35%-65% relative humidity, 48 hours prior to and after installation.
5. Store wall covering and adhesive at a minimum of 65°F and 35%-65% relative humidity 48 hours prior to installation, preferably on site. This acclimation will reduce expansion and contraction.
6. Remove dirt and dust by vacuum.
8. Insure that all patching is sufficiently cured prior to installation.

Description: Solvent Free Drywall and Panel Adhesive

Flammability: Non-Flammable

Open Time: 30-40 minutes

Clean Up: Water when wet; Safety solvent or mineral spirits when dry.

Shelf Life: One year in closed container.

Limitations: Do not subject to temperatures below 10°F. If frozen, warm to at least 70°F for 24 hours and stir before using. For interior use only.

Packaging: • 30 Ounce Cartridge (12/case) • 60 cases per pallet

For The Installation Of: • Gypsum Drywall
• Hardboard • Common Wood Paneling

For Use Over: • Dry Concrete • Plaster • Wood
• Plywood • Brick

Prior To Installation:

1. Insure that wall is sound, smooth and free of depressions and protrusions.
2. Fill any depressions or cracks with a good grade of patch.
3. The wall must be free of flaking paint, dust, old adhesives, curing agents, parting compounds, oil, grease, wax, and any other contaminant that may hinder the performance of an adhesive. Existing glossy surfaces must be roughened for good adhesion.

Installation Instructions: Apply continuous 3/8" bead to studs or framing surfaces. Apply 2 about 1/2" apart at panel joints. Do not spread over area larger than can be covered in 30 minutes to avoid skinning over. Do not use over vinyl coated board.

Fastening: Attach gypsum drywall to framing with staples at 6" o.c. around gypsum perimeter and no field fasteners along interior studs. Field fasteners may be eliminated if walls are assembled in the horizontal position.

First Aid: Skin- Soap and water. Eyes- Flush with water, lifting upper and lower lids occasionally. Ingestion- Do not induce vomiting. Call physician or transport to an emergency facility. Inhalation- If affected, remove individual to fresh air. Use only in well ventilated areas.