



product

Specification

WOODY P88

Non-Flammable Wood Flooring Adhesive



WOODY P88 Non-Flammable Wood Flooring Adhesive has been the very foundation of our wood flooring program. WOODY P88 is and has always been, the most trusted wood flooring adhesive around for the installation of parquet and engineered plank.

- Solvent/Rubber Based Performance
- High Solids
- Fast Early Grab
- Easy to Trowel

Description: Chlorinated Solvent Based Wood Flooring Adhesive

Flammability: Non-Flammable

Open Time: 30 - 45 minutes

Clean Up: Clean wet adhesive and tools with white cloth and mineral spirits.

Shelf Life: One year in closed container.

Packaging: 5 Gallon

For The Installation Of:

- Parquet • Engineered Wood Plank

For Use Over:

- Concrete • APA Approved Plywood • Underlayment
- Grade Particle Board • OSB • Terrazzo • Latex
- Portland Cement Underlayment • Gypsum Cement Underlayment

Instructions For Use:

1. Condition room and materials at 65°F for 48 hours prior to, during and after installation.
2. Sweep floor and remove any dirt or debris prior to installation.
3. Make sure floor is free from grease, oil, paint, or other contaminant that might interfere with the bond of the adhesive.
4. Do not install on floors with high moisture or alkali content.
5. Spread adhesive with the appropriate trowel making sure to maintain trowel notchings throughout the installation.
6. Allow the adhesive to flash for 45 minutes or until dry to touch prior to installing the flooring
7. Apply only as much adhesive that can be installed within 1 hour.
8. Press flooring firmly into adhesive.
9. Roll in both directions according to floor manufacturers recommendations.
10. Clean wet adhesive and tools with white cloth and mineral spirits.

Trowel Requirements

3/16 x 1/4 x 1/2

50 square feet /gallon

- Engineered Plank (4 inch wide max)
- Prefinished Parquet

